

## Cavity pressure sensor

## Unisens with front ø4 mm

Quartz sensor for cavity pressures up to 2 000 bar for injection molding of plastics.

- ideally suited for industrial applications
- sensor front can be machined to adapt to the cavity wall (except for coated versions of the sensor)
- exchangeable cable

## Description

The Unisens quartz sensor for cavity pressure Type 6157C... has a front diameter of 4 mm. An O-ring seals the annular gap of <10  $\mu$ m between sensor and mounting bore and thereby also center aligns the sensor in the bore.

The pressure acts over the entire front of the sensor and is transmitted to the quartz measuring element, which produces a proportional electric charge (pC = Picocoloumb). This is converted into a voltage  $0 \dots 10 \text{ V}$  in the amplifier and is then available as an amplifier output.

All parts of the sensor are corrosion-resistant. The exchangeable cable is screwed to the sensor with a tight seal. The connector is self-locking and splash-proof.


For multi cavity applications the sensor Type 6157C... is used without the single-wire connector Type 1839. For 4 channel applications the sensor Type 6157C... is mounted with the Multi-Channel Connector Type 1722A4... and for 8 channel applications with the Multi-Channel Connector Type 1722A8... .

This sensor is available with several types of connecting cables (see page 2).

## **Application**

This diaphragm-free sensor measures cavity pressures up to 2 000 bar during injection molding. It is particularly suitable for optimizing, monitoring and controlling the injection molding process of thermoplastics and elastomers.





For abrasive melts (e.g. filled with glass fibers or carbon fibers, thermosets, BMC/SMC), these sensors are available as Types 6157CC... (0 ... 200 °C)/CD... (0 ... 300 °C) with a coated front.


#### Technical data

Range	bar	0 2 000
Overload	bar	2 500
Sensitivity	pC/bar	-9.4
Linearity, all ranges	% FSO	≤±1
Operating temperature range		
Mold (sensor, cable)		
Type 6157CA/CC	°C	200
Type 6157CB/CD	°C	300
Melt (at the front of the sensor)	°C	<450
Connector	°C	0 200*
Insulation resistance		
at 20 °C	Ω	>10 <sup>13</sup>
at 200 °C	Ω	>10 <sup>12</sup>
at 300 °C	Ω	>10 <sup>10</sup>


\* During machine down time the mold temperature may rise up to 240 °C, without causing any damage to the sensor. Note that measuring errors may temporarily result.



#### Sensor variants










Fig. 1: Pressure sensor Type 6157C with coaxial cable

Fig. 2: Pressure sensor Type 6157C for high temperature applications with coaxial cable

Fig. 3: Pressure sensor Type 6157C with sngle-wire cable

Fig. 4: Pressure sensor Type 6157C with conductive spacer sleeve

### Fig. 1: Pressure sensor Type 6157C with coaxial cable

Sensor including an exchangeable high temperature cable with a connector for operating temperatures up to 200 °C.

# Fig. 2: Pressure sensor Type 6157C for high temperature applications with coaxial cable

Sensor including an exchangeable steel-braided thermoset plastic cable (Polyimide) with connector for operating temperatures up to 300 °C (Connector 200 °C).

## Fig. 3: Pressure sensor Type 6157C with single-wire cable

Alternative version of the sensor with single-wire technique for simplified and flexible installation in the mold. The sensor Type 6157C...S... is equipped with a single-wire cable with a very small cross-section. The single-wire cable is exchangeable and can be cut to length as required by the user. With the single-wire technique the electrical shielding is provided by the mold. Both the cable and the connector therefore have to be completely integrated into the mold. For easy installation a connector is supplied which is self locking and splash proof.

# Fig. 4: Pressure sensor Type 6157C with conductive spacer sleeve

Sensor including a conductive spacer sleeve for cable-free connection onto a contact element.

### Special versions

Coated front (abrasion protection)

Type 6157CA... with coated front:

Type 6157CC...

• Type 6157CB... with coated front:

Type 6157CD...

### Installation

The sensor is normally fixed in the mounting bore with the mounting nut (Type 6457), but a spacer sleeve (Type 6459) can also be used.

The sensor front forms part of the cavity wall. The sensor should therefore be adapted so that its front comes exactly flush with the cavity wall. Its front can be machined up to 0.5 mm (except with a coated front!). Full details can be found in the operating instructions.


The sensor is center aligned in the 4 H7 bore.

The single-wire cable must be installed completely in the mold. This connector is fitted in the mounting plate and this secured in a recess in the mold. The identification plate should be fixed nearby, indicating the type of sensor and its sensitivity.

Page 2/6



## Cable and amplifier for measuring chains with sensor Type 6157C








Fig. 5: Sensor Type 6157C with charge amplifier Type 5159A





4-channel cable Type 1995A on connector Type 1722A4	8-channel cable Type 1997A on connector Type 1722A8
Type 5887A1	Type 5887A2
	Type 5887A3
	Type 5887A4

Fig. 6: Sensor Type 6157C with ComoNeo monitoring system ComoNeo Typ 5887...

Page 3/6



## Installation examples




Fig. 7: Installation with mounting nut Type 6457 \* Adjust length




Fig. 9: Installation with conductive spacer sleeve




Fig. 8: Installation with spacer sleeve Type 6459 \* Adjust length




Fig. 10: Sensor with machined front (max. 0.5 mm)




Fig. 11: Single-wire-Fischer-connector Type 1839






Fig. 12: Sensor, cable, mounting plate (Mat. No. 3.520.328) and identification label (Mat. No. 3.520.899)




Fig. 13: Mounting plate (Mat. No. 3.520.328)

<ul> <li>Accessories included</li> <li>Mounting nut</li> <li>Spacer sleeve (L = 70 mm)</li> <li>Conductive spacer sleeve (L = 70 mm)</li> </ul>	Mat. No./Type 6457 6459 1720A3	<ul> <li>Coaxial cable 0 200 °C with M4 and Fischer connector.</li> <li>Steel braided coaxial cable 0 200 °C with M4 and Fischer connector</li> </ul>	1645C
<ul> <li>Mounting plate</li> </ul>	3.520.328	(wear resistant substitute)	1963A
Identification label	3.520.899	• Coaxial cable 0 200 °C with M4 and	
<ul> <li>Connector (for single-wire Types with</li> </ul>		MiniCoax connector	1650A4P
connector)	1839	<ul> <li>Hightemperature coaxial cable 0 300 °C</li> </ul>	
<ul> <li>O-ring, diameter 2,5x0.65 mm,</li> </ul>		with M4 and Fischer connector	1955A
(for Types up to 200 °C)	1100A57	<ul> <li>Single-wire cable with M4 connector</li> </ul>	
• O-ring, diameter 2,5x0.65 mm,		L = 1.5 m	1666A2
(for Types up to 300 °C)	1100A67	<ul> <li>Single-wire cable with M4 connector</li> <li>L = 5 m</li> </ul>	1666A4
Optional accessories			
Dummy sensor	6545	<ul><li> Crimped pin</li><li> Crimpset with tools</li></ul>	65003747 1381A0
<ul> <li>4-channel connector up to 120 °C</li> </ul>			
(for MiniCoax and single-wire cable)	1722A4	Checking Tools	
<ul> <li>8-channel connector up to 120 °C</li> </ul>		<ul> <li>Limit plug gage, diameter 4 mm, tolerance H7</li> </ul>	65007799
(for MiniCoax and single-wire cable)	1722A8	Checking tool	65014072
<ul> <li>4-channel connector 120 200 °C</li> </ul>			
(for single-wire cable)	1708	Mounting Accessories	Туре
8-channel connector 120 200 °C		• Extraction tool for Types up to 200 °C	1315A
(for single-wire cable)	1710	<ul><li>Extraction tool for Types up to 300 °C</li><li>Mounting piece for connector</li></ul>	1362A 1401
Contact elements 1-channel		Mounting piece for connector     Mounting wrench	1383B
for single-wire types	1712B0	Dismounting cabel auxiliary tool	1300A32
Contact elements 4-channel	1250	(incl. fork wrench SW4/SW5 5.210.164)	.500/ 152
for single-wire types	1714B0	( 3	



## Ordering key

0 ,					 _ (		- I
Sensor		Ty	pe 6157C	<b>□</b> - <b>□</b>	_  - l ▲	ᆜ└ ▲ ▲	╛┕
up to 200 °C	Α	_			Î	Î	ĺ
up to 200°C, sensor front coated	С			_			
up to 300 °C	В	_					
up to 300 °C, sensor front coated	d						
Sensor and mounting		_					
Unisens	U						
		_					
Mounting with mounting nut Type 6457	M						
Mounting with spacer sleeve Type 6459	S						
Mounting with conductive spacer sleeve	N						
Reserve	R	]					
Neserve	11						
Cable		1					
Single-wire-cable (PTFE), only for version A and C	S						
Coaxial cable (PFA D2), only for version A and C	К				 		
High temperature coaxial cable, only for version A and C	н						
without cable	X						
Connector							
Fischer KE102 (cable K)	F						
MiniKoax (cable K)	M						
with connector type 1839 in scope of delivery (cable S)	E						
without connector type 1839 in scope of delivery (cable S)	G						
Cable design							
No cable	xxx						
L = 0.2 m, only cable K, connector F or M (coaxial)	0.2	-					
L = 0.4 m, cable K, connector F or M (coaxial) cable H, connector F (coaxial)	0.4						
L = 0.6 m, only cable K, connector F or M (coaxial)	0.6	_					
L =0 ,8 m, only cable K, connector F or M (coaxial)	0.8	_					
L = 1.0 m, only cable K, connector F (coaxial)	1.0	_					
L =1,2 m, only cable K, connector F or M (coaxial)	1.2	_					
L = 1.5 m, cable K, connector F or M		_					
cable S, connector E or G	1.5						
L = 1.6 m, only cable K, connector F or M (coaxial)	1.6						
L = 2.0  m, only cable K, connector F or M (coaxial)	2.0						
L = 2.5 m, only cable K, connector F or M (coaxial)	2.5						
L = 3.0 m, only cable K, connector F or M (coaxial)	3.0						
L=5.0 m, only cable S (Single-Wire)	5.0						
L = 0.10 5 m, only cable K or H (coaxial)	-sp						
Single-Wire cable, M4 – crimp pin, L= 0.04 1.5 m contact element Type 1712 and 1714), only for cable S and connector G	Zsp						

This information corresponds to the current state of knowledge. Kistler reserves the right to make technical changes. Liability for consequential damage resulting from the use of Kistler products is excluded.