

maXYmos TL

Type 5877A...

XY Monitor for Complex Evaluation of Curves

The maXYmos TL (Top Level) captures, analyzes and evaluates XY curves of two measurands that have to stand in a precisely defined relationship to each other. Such curves arise in applications such as

- Press fitting of bearings or valve seat rings
- · Riveting and flanging of casing parts
- Turning and swiveling of joints
- Turning of key switches
- Movement of drawer slides
- · Compression and extension of shock absorbers
- · Pressing of snap-in elements

The measurement curves can be used to assess the quality of an individual stage of production, an assembly or the product as a whole.

Description

The functions of this XY monitor range from simple, single-channel force-displacement monitoring to complex multichannel applications for use in assembly and product testing. The monitor, which can have up to eight cascadable channel pairs, is designed to satisfy the most demanding users who require maximum user-friendliness, user comfort and flexibility. With a wide range of powerful evaluation objects, even very complex XY curves can be evaluated. Building on the maXY-mos BL (Type 5867B...), the maXYmos TL offers a whole range of additional evaluation possibilities. For example, the GET-REF object is able to determine the coordinates of significant points on a curve, e.g., the position of a snap-in point, and pass them to a CALC object. This then calculates, e.g., the distance between two such snap-in points and evaluates it.

- Up to 8 XY channel pairs via cascadable measuring modules (MEM)
 The main features of each MEM:
- Curve capture according to Y=f(X), Y=f(X,t), Y=f(t), X=f(t)
- Curve evaluation with UNI-BOX, ENVELOPE, LINE-X, LINE-Y, NO-PASS, HYSTERESIS-Y, HYSTERESIS-X, GRA-DIENT-Y, GRADIENT-X, TUNNELBOX-X, TUNNELBOX-Y, BREAK, CALC, AVERAGE, GET-REF, SPEED, TIME, DELTA-Y, DIG-IN, INTEGRAL, INFLEXION
- Up to 10 evaluation objects (EOs) per curve



- Dynamic referencing of evaluation objects in X and Y directions
- 128 measurement programs for 128 part types
- Measurement curve with up to 8 000 XY value pairs
- Short evaluation time
- EtherNet TCP/IP for measurement data, remote maintenance and channel cascading
- Choice of bus types available via menu: EtherNet/IP, PROFINET, EtherCAT, CC-Link
- Dig-IO (24 V) for control and results
- 2 switching signals on X or Y threshold
- 2+1 USB for USB stick and notebook
- Channel X: Pot, ±10 V, LVDT, incremental, SSI
- Channel Y: Strain gauge, ±10 V or piezoelectric sensors
- Multiple data export formats, e.g. Q-DAS, QDA-9, IPM 5.0, XML, CSV, PDF
- Desktop, wall or front panel mounting; can be repositioned in a few easy steps
- Informative NOK cause diagnosis, process value trend patterns, etc.
- Process value table with free choice of contents
- Selected process values for the curve graph
- Warning and alarm messages, e.g., NOK in series
- · Acces protection with various levels of access
- Display module (DIM) with 10,4" color touch screen and front-mounted USB slot

For more information visit www.kistler.com/maxymos



measure. analyze. innovate.

Technical Data

Measuring and Evaluation Module (MEM)

Degree of protection	IP	40
Operating temperature	°C	0 45

Measuring Channels

Number	1 X-channel, 1 Y-channel	
Sampling rate X/Y max.	kHz	20
Resolution per (analog) channel	bit	24
Accuracy class	%	0,3
Low-pass filter per channel	Hz	in stages 0,1 2 000

Sensors channel X

Sensor Type 1		Potentiometer	
Linearity error	%FS	0,05	
Track resistance	kΩ	1 5	
Supply voltage	V	4 (4,16)	
Connection system	3-wire		
Wiper current	μA	<0,1	
Sensor Type 2		Process signal ±10 V	
Signal output	V	±10	
Linearity error	%FS	0,05	
Transmitter supply	VDC	DC 24	
	mA	200	
Sensor Type 3		Incremental	
Signal output	Sin	Sinus/Cos, RS422 (A+B)	
Reference marker		yes	
Counting depth	bit	32	
Counting frequency	MHz	10 (RS422)	
	MHz	1 (sine/cos)	
Sensor Type 4		Inductive	
Principle	L	VDT, half-, full-bridge	
Sensor supply	Veff	1,8 ±5 %	
	kHz	5,2 ±0,5 %	
Linearity error	%FS	0,1	
Frequency range (-3 dB)	kHz	0 1	
Sensor Type 5		SSI	
Signal output		RS422	
Clock frequency max.	MHz	1	
			

Sensors channel Y

Sensor Type 1		Piezo
Measuring range	Number	4
Measuring range 1	рС	±100 ±1 000
Measuring range 2	рС	±1 000 ±10 000
Measuring range 3	рС	±10 000 ±100 000
Measuring range 4	рС	±100 000 ±1 000 000

Range selection		automatic
Drift	pC/s	0,05
Linearity error	%FS	0,1
TKE	ppm/K	<±100
Frequency range (-3 dB)	kHz	0 5
Low-pass filter (in stages)	Hz	in stages 0,1 2 000
Sensor Type 2		DMS
Measuring range	mV/V	0 ±5
Supply voltage	VDC	5
Connection system		4-wire, 6-wire
Bridge resistance	Ω	>300
Linearity error	%FS	0,05
Frequency range (-3 dB)	kHz	0 5
Sensor Type 3		Process signal ±10 V
Signal output	V	±10
Linearity error	%FS	0,05
Transmitter supply	VDC	24
	mA	200

Cycle Control

Start – Stopp	Dig-Input / Fieldbus / Threshold X / Threshold Y /
	Time / Manual

Measuring Functions

Measurement curve according to Y=f(X), Y=f(t), Y=f(X,t), X=f(t)

Curve Memory

Current curve	XY-pairs	max. 8 000
Historic curves (for NOK diagnosis)		the last 500

Evaluation Objects (EOs)

EO types

UNI-BOX, ENVELOPE, LINE-X, LINE-Y, NO-PASS, HYSTERESIS-Y, HYSTERESIS-X, GRADIENT-Y, GRADIENT-X, TUNNELBOX-X, TUNNELBOX-Y, BREAK, CALC, AVERAGE, GET-REF, SPEED, TIME, INTEGRAL, DELTA-Y, DIG-IN

Reference points

Absolute X,

Dynamic: Block point X,

Dynamic: X on trigger Y,

Referencing in X and Y directions possible

Data Export

Editing

Format	Q-DAS®, XML, CSV, PDF, QDA9, IPM 5.0
Destination	USB, Server
Medium	USB, Ethernet

Remote, via touchpanel



measure. analyze. innovate.

Туре	across VNC, or DIM		
Serielle Interfaces			
Ethernet	TCD/ID 100 Pag	a TV with 2 Dort Switch	
USB		e TX with 2 Port Switch	
		x USB (Device + Host)	
BUS	DDOEINET	CC-Linl	
	PROFINEI	, EtherCAT, EtherNet/IF	
		2 Port Switch	
Dig-In/Out			
Norm		DIN EN61131	
Level state "0"	V	0 5	
Level state "1"	V	15 30	
Number of inputs		22	
Input current max.	mA	8 (at 24 V)	
Number of outputs		23	
Output current max.	mA	100 (at 24 V)	
Number Switchover via		128 Menu/DigIn/BUS	
Switching Signals			
Switching Signals Number		2	
Number			
Number Channel assignment	Thresh	X or Y (selectable)	
Number		X or Y (selectable)	
Number Channel assignment		X or Y (selectable) old X exceed/underrun old Y exceed/underrun	
Number Channel assignment Switching point		X or Y (selectable) old X exceed/underrun old Y exceed/underrun DigOut or Fieldbus	
Number Channel assignment Switching point Output		X or Y (selectable) old X exceed/underrun old Y exceed/underrun DigOut or Fieldbus Free-running or latch	
Number Channel assignment Switching point Output Mode		X or Y (selectable)	
Number Channel assignment Switching point Output Mode Influence on evaluation Real-time Reactions		X or Y (selectable) old X exceed/underrun old Y exceed/underrun DigOut or Fieldbus Free-running or latch	
Number Channel assignment Switching point Output Mode Influence on evaluation	Thresho	X or Y (selectable) old X exceed/underrun old Y exceed/underrun DigOut or Fieldbus Free-running or latch	
Number Channel assignment Switching point Output Mode Influence on evaluation Real-time Reactions Switching signals EO type "NO-PASS"	Thresho	X or Y (selectable) old X exceed/underrun old Y exceed/underrun DigOut or Fieldbus Free-running or latch No	
Number Channel assignment Switching point Output Mode Influence on evaluation Real-time Reactions Switching signals	Thresho	X or Y (selectable) old X exceed/underrun old Y exceed/underrun DigOut or Fieldbus Free-running or latch No	

Environment		
Working temperature	°C	0 45
Storage temperature	°C	0 50
IP degree of protection (EN 60529)		
- Connector and cable running	IP	53
downwards		
 Standard rail version 	IP	20
Display Module (DIM) Size	Inches	10,4
Color	Inches	·
		yes
Touchscreen		yes
Resolution	Pixels	800x600 (SVGA)
Technology		TFT-LCD
Backlighting		LED
Supply voltage (of MEM)	VDC	24
Power consuption	VA	6
IP degree of protection (EN 60529)		
– Front	IP	65
_ Rear	IP	53

°C

Operating temperature range

0 ... 45

Housing: order no. 734-603



measure. analyze. innovate.

The System Concept

Basic Components

The maXYmos TL consists of two basic components: the measuring and evaluation module (MEM), which works entirely autonomously and supports one XY channel pair each, and the display module (DIM).



MEM with Display Module

The MEM and DIM can either be installed separately from each other, in which case they are connected only via the optional connecting cable type 1200A161A2,5/5.



.... or they can be used as a compact unit. In this case the MEM is inserted into the rear slot of the DIM, forming a secure mechanical and electrical connection:




MEM as Black Box Module

Since the measuring and evaluation module (MEM) works entirely autonomously, it can also be operated without the DIM. In this case, setup and process visualization are carried out via the graphical user interface (GUI), which can be transferred onto a PC. Access is by VNC via the Ethernet interface or USB.



Expandable for up to Eight XY Channel Pairs

For this purpose, the MEMs are connected to the Ethernet interface via patch cables. External switches are not required. The Ethernet is simply looped through the MEMs via the In-Out sockets.





Evaluation Objects (EOs) for maXYmos

The measurement curve must not Type ENVELOPE		The line may not be crossed.	Type NO-PASS	
cross the upper or lower line of the envelope. This evaluation object is easy to master.	IO NIO	Otherwise, NOK and "NO-PASS" real-time signal.	IO NIO	
The line must be crossed once. An X-value at the point of intersection is monitored.	Type LINE-X IO NIO Y X	The line must be crossed once. An Y-value at the point of intersection is monitored.	Type LINE-Y IO NIO NIO X X	
Entry and exit as specified. No crossing of "closed" sides allowed. Each side can be defined as entry or exit.	Type UNI-BOX IO NIO	Evaluates the average of all Y-values in the box region.	Type AVERAGE NIO NIO	
Entry and exit as specified. Crossing of the "closed" sides generates a real-time signal.	Type TUNNELBOX-X IO NIO Y 10 Y NIO X X X	Entry and exit as specified. Crossing of the "closed" sides generates a real-time signal.	Type TUNNELBOX-Y IO NIO Y X X	
Box detects significant curve features and their XY coordinates in the expectancy range. This information can be used as reference points for other EOs or as an input for the CALC object	Type GET-REF Y X1 X2 Y1 Y2 X	Evaluation criterion is the time between the entry and exit points in a special box.	Type TIME IO NIO Y X X	
Evaluation criterion is the speed between the entry and exit points in a special box.	Type SPEED IO NIO Y X X	Object references two selectable process values and performs calculations, e.g. the X-difference between two ripples, and evaluates them.	Type CALC IO NIO Y X2-X1=IO X X1 X2 X1 X2	
A defined gradient change is expected within the expectancy range (box) and can be used as a further switching condition in the sequence.	Type INFLEXION IO NIO X X	Provides NOK and online signal in case of sudden gradient change within an expectancy range (box), e.g. in case of tool breakage.	Type BREAK IO NIO Y X Y X	





measure, analyze, innovate,

Measuring and Evaluation Module (MEM)

Interfaces

The module, which features an XY channel pair and all data and control interfaces, forms the heart of the XY monitor.







Sequencer Mode

The Sequencer Mode in the maXYmos TL allows programming of sequence controls, which are used to control the processes. An independent program can be created for every measurement program, using the freely programmable digital input and outputs to poll or output special, process-relevant conditions, for example. The following elements are available:

Important Features of maXYmos TL Sequenzer Mode:

- 7 freely programmable digital inputs
- 7 freely programmable digital outputs
- Up to 256 elements for each measurement program
- "Cam function" for the X and Y axis
- MP toggle function
- 20 control measurement programs
- · 108 regular measurement programs
- 100 variables



MP Switching Element, by using this element you can change to and return from one of the 20 master measurement programs in one of the 107 submeasurement programs.



Calculator Element, by using this element you are able to calculate with determined values.



Measurement Start/Stop Element: this element starts and stops the measurement. When measurement stops, evaluation is performed according to the parameterized evaluation elements.



Timer Element: this element delays execution of the subsequent element by the configured time. Use as a dwell time under force, for example.



IF/ELSE Element, this element permits a conditional branch, i.e. a branch in the sequential program according to the query condition or result.



Restart Element, branching option to the start of the sequence.





Piezo Operate Element, this element is used to perform a variable measurement start/stop of the integr. charge amplifier included in the sequence.



Threshold Element, this element serves to record the learned positions on the X and Y axes. These positions act as a progressive switching or query condition in the sequence.



Output Element: when this element is activated, the corresponding configured output is set on the device.



Input Element: when this element is activated, the system waits for the configured digital input signal and then continues the sequence.




Dialog Element, this element enables interaction with the user. It can be used, for example, to forward useful information to the user. The dialog must be confirmed by the user at the visualization or will be hidden automatically after a configured period of TIME.



measure, analyze, innovate.

Product testing example: Distance check between two snapin points of a latch. The two GETREF boxes supply the coordinates of the snap-in points to the CALC objects. These calculate and evaluate the distances in the X and Y directions.



Housing Concept and Installation Variants

With the universal housing concept, different mounting configurations can be realized in a few easy steps. This allows the machine designer to change to a different mounting configuration at any time.

Desktop and Wall Mounting

A desktop unit can be changed into a wall-mounted version in a few easy steps.



Front Panel Mounting

After removing the fixing bracket and rear frame, push the display through the front panel opening. Then screw the frame back on. The measuring module (MEM) can now be pushed into the slot of the display module if required.




This information corresponds to the current state of knowledge. Kistler reserves the right to make technical changes. Liability for consequential damage resulting from the use of Kistler products is excluded.

DIN Rail Mounting

The measuring module (MEM) can be mounted on a DIN rail with a optional fastening clip. This makes it possible to house the sensitive connection area of the MEM inside the control cabinet, where it is well protected, while placing the better protected display module (DIM) in the visible area.

Advantages: There is only a monitor cable leading to the display. At the same time, the degree of protection in the monitor area is increased to IP65.



Functional Principle with DIM Cable Extender

DIM Cable Extender as an active cable extension between maXYmos MEM and Display DIM with a range of up to 100 m. The DIM Cable Extender Type 1200A163 is inserted into the rear panel of the maXYmos DIM Type 5877AZ000 display and fixed in place with two screws.




The DIM Cable Extender is inserted at the rear portion of the display. The DIM Cable Extender is supplied with 24 V of power (the display is then supplied by the DIM Cable Extender). The DIM Cable Extender is connected to one or several maXYmos units via an Ethernet cable.

Page 8/11




Dimensions

Measuring and evaluation module (MEM)




Note: Observe minimum spacing of >10 mm between the MEM's!

Display module (DIM)






Display module (DIM) switch panel mounting




Display module (DIM) – panel cut-out for switch panel mounting. With lateral distance to adjacent displays.





measure, analyze, innovate,

Accessories	Туре	Ordering Key for	
 Display module (DIM) 	5877AZ000	XY Monitor maXYmos TL	Type 5877AK 🔲 🔲
Set of connectors maXYmos TL for	5877AZ010		<u>↑</u> <u>↑</u>
sensors, digital I/O and supply			
 Connecting cable between MEM and 	1200A161A2,5	Measuring and evaluation module (MEM)	0 —
DIM, length 2,5 m			
 Connecting cable between MEM and 	1200A161A5	XY monitoring system for 1 XY channel pa	ir
DIM, length 5 m		consisting of 1 display module (DIM)	1
Ethernet connecting cable	1200A49A3	Type 5877AZ000 and 1 measuring and	'
between MEM's, length 0,5 m		and evaluation module Type 5877A	
Ethernet connecting cable	1200A49		
between MEM's, length 5 m		XY monitoring system for simultaneous	
• Power supply 90 - 240 VAC/24 VDC	5779A3	measurement of multiple XY channel pairs	
ready for connection max. 30 VA,		2 XY channel pairs	2
Euro/UK/USA/Australia connector		3 XY channel pairs	3
 Power supply 100 - 240 VAC/24 VDC 	5867AZ012	4 XY channel pairs	4
ready for connection max. 60 VA,		5 XY channel pairs	5
Euro connector		6 XY channel pairs	6
 DIN rail clip for MEM control 	5700A31	7 XY channel pairs	7
cabinet mounting		8 XY channel pairs	8
DIM Cable Extender	1200A163	·	
		CC-Link	
52 33	33-	PROFINET, EtherCAT, EtherNet/IP	1



Windows®-Software maXYmos PC (Basic) 2830A1

- Organize firmware updates
- Save device settings in a backup file
- Restore settings to the device

(included in the scope of delivery of the measuring and evaluation module Type 5877A)

Windows®-Software maXYmos PC (Plus) 2830A2

Like Basic version, but in addition:

- All device settings applied on PC (Setup editor)
- Log explorer opens and interprets exported test records
- Generation of an Excel® statistical file with selected process values
- Cursor measurement, bundle presentation of curves, etc.
- Final Y(X) curves can also be presented as Y(t) or X(t)
- PDF print function for test records

Included Accessories for Type 5877AK0X
 Set of connectors maXYmos TL for sensors, digital I/O and supply
 Type/Mat. No.
 5877AZ010

Windows software maXYmos PC Basis 2830A1

Included Accessories for Type 5877AK1X Type/Mat. No.

One display modul (DIM) 5877AZ000
 Set of connectors maXYmos TL for sensors, 5877AZ010 digital I/O and supply

Windows software maXYmos PC Basic 2830A1

Included Accessories for Type 5877AK2-8X Type/Mat. No.

One display modul (DIM) 5877AZ000
 n Set of connectors maXYmos TL for sensors, digital I/O and supply
 n-1 Ethernet connecting cable between 1200A49A3

MEM's, length 0,5 m

Windows software maXYmos PC Basic 2830A1

Windows $^{\circ}$ and Microsoft Excel $^{\circ}$ are registered trademarks of the Microsoft Corporation.

Page 11/11